

YOU ARE POWER

Chiron GT1 is so much more than a conventional curved treadmill. With a unique electronic system, a variety of training programs is made possible without the expense of electricity.



Smart Built-in Programs

21.5" touchscreen provides a rich workout experience and entertainment.

CloudRun

Experience running on world-renowned routes and setting up personalized training programs.

Auto-Resistance

Test your endurance with 10-level resistance.



Durability

The sturdy and savvy design ensures low maintenance and reliable performance.



Eco-Friendly

Power up the TFT touchscreen panel within your strides, enabling performance tracking and entertainment. Store the power for later use.



Prevention and Performance

Innovative lights help visualize live performance by changing color according to the heart rate zone or the watt zone.

CHIRON *GT1*
ECO TREADMILL

CHIRON **GT1**

ECO TREADMILL



CONSOLES SPECIFICATIONS

Display	21.5" touchscreen
Screen Size (LXW)	560 x 370 mm
Screen Adjustable Angle	15 degrees up and down
Speakers	Two
Third-party APP Connection	Ala Cloudrun, Youtube, Netflix, Spotify
Heart Rate	NFC, Bluetooth
Network Connection	Wi-Fi
Interface	Touchscreen Panel

SPECIFICATIONS

Power Generation	Fully self-generating system
Program	Target Distance, Target Time, Target Calories, Target Watts, Target Heart Rate, Interval, Cross Country, Weight Loss, History
Displayed Data	Time, Distance, Calories, Speed, Heart Rate, Watts, Resistance, Generated Power
Electronic Brake	Yes
Resistance	10-level Dynamic Resistance 14-level Watt Output-Based Resistance (Max. 150W)
Light Bar Display	Watt Zones (6-segment display) Heart Rate Zones (6-segment display)
Armrest	Bilateral
Surface Type	TPE Injection molded slats
Water Bottle Holder	1
Transport Wheels	2
Leveling Feet	2
Running Area	1680*480mm (66"X19")
Machine Dimensions	1863*916*1688mm (LxWxH)
Machine Weight	158kg (348lbs)
Max User Weight	180kg (39 7lbs)
Min-Max User Height	150 - 210cm (4.11"- 6.11")
Max Speed	Unlimited
Dimensions	1850*1005*765mm (LxWxH)
Shipment Weight	202kg (444lbs)
Container Quantity	20'-18pcs/ 40'-36pcs/ 40'HQ-36pcs (Unable to increase loading capacity due to increased height)
Group Training	GPTfit

POWER AND HEART RATE DISPLAY

The side lights shows 6 power levels and 6 heart rate zones. When connecting to wearable heart rate devices, the light will change color according to the heart rate zones. Trainers can identify the zone change to adjust the trainee's training intensity and the course content on the spot.

WATT ZONES	LED INDICATOR	Zone 0	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5
		Blue	Aqua	Green	Yellow	Red	Magenta
	Watt	0~30	30~50	50~70	70~90	90~110	110~

HEART RATE ZONES	LED INDICATOR	Zone 0	Zone 1	Zone 2	Zone 3	Zone 4	Zone 5
		Blue	Aqua	Green	Yellow	Orange	Red
	HEART RATE ZONES	Daily Life	Warm Up	Fat Burn	Aerobic	Anaerobic	Maximum Effort
	%MHR	~50	50~60	60~70	70~80	80~90	90~
	Training Intensity%	~55	55~60	60~65	65~75	75~85	85~
	TRAINING FUNCTIONS	Facilitate warm-up and energy recovery	Improve metabolism	Enhance aerobic fitness	Increase speed and lactate threshold	Anaerobic. Sprinting pace; unsustainable for a long period of time	



Obeat3 NFC **NFC quick pairing**
Recommended with Obeat3 NFC optical heart rate armband



39F., No.758, Zhongming S. Rd., South Dist., Taichung City 40255, Taiwan

tel : +886-4-2260 8341 fax : +886-4-2260 8346 www.alatech.com www.attacusfitness.com