Battery

1. Current time
2. Upload file
3. Battery low indicator
4. Connection to sensor
5. Connection to mobile phone
6. Speed display
7. Heartbeat display
8. Pedaling frequency display
9. Information display

⊖ Enter/Hot Key/Start bicycling/ Backlight key

◔ Right / Down arrow key

↺ Exit / Back / Stop bicycling key

Front

Reverse

Included Accessories

Holder	Fixing pad
Cable tie×4	CR2032 Button battery

● lock

🔓 unlock

COIN

Battery

Battery cover

Operation flow

Switch the Function Mode

Standby mode (no screen)

TRAINING PROG.	MEMORY FILE	HOT KEY SET	SENSOR SET	PHONE SYNC

EXERCISE STAT.	SYSTEM SET	USER SET	PAIRING SENSOR

Start Bicycling

Standby mode (no screen)

00:00:00 → TRIP DST → CALORIE → GRADIENT

* If the product has not recieved a signal for 4 hours during bicycling, Exercise mode will automatically end and return to standby mode. For more detailed instructions, please see manual.

① **Power up for the first time**

- Press ⊖ to turn on the product and select your appropriate language, and then press ↺ to exit to standby mode.
- Refer 1-1 Applications of manual to pair it with optional Bluetooth 4.0 sensors or your smartphone as required.
- Refer 3-1 System Setup of manual to setup your data.

② **Key operation**

- To switch the different menu items, press ◔.
- To enter selected screen, press ⊖ .
- To point to the flashing setup item, press ⊖.
- To change the settings, press ◔.
- To exit the Exercise or Settings screens, press ↺.
- Press ⊖ to turn on the backlight for 5 seconds.
- To start bicycling, press ⊖.
- To browse instant bicycling screens*, press ⊖.
- To stop bicycling, press ↺ once and then press it again to save data.

Installation

Stem

Handlebar

✕

Please download the latest version and complete user manual at: